



# REGENERATION LAMPS



Warning: Do not obstruct operator's working view.

Lamps	Event	Operator Action
	Active regen in process	<ul style="list-style-type: none"> <li>• No action required</li> </ul>
	Active regen needed	<ul style="list-style-type: none"> <li>• Make sure Regen Switch is in Automatic position (middle), not Disabled position (bottom)</li> </ul>
	Warning: Active regen required	<ul style="list-style-type: none"> <li>• Stop machine</li> <li>• Put transmission in neutral</li> <li>• Apply parking brake</li> <li>• Press and hold top position of Regen Switch for at least 2 seconds</li> </ul>
	Warning: Active regen required within 10 minutes	<ul style="list-style-type: none"> <li>• Stop machine</li> <li>• Put transmission in neutral</li> <li>• Apply parking brake</li> <li>• Press and hold top position of Regen Switch for at least 2 seconds</li> </ul>
	Active regen disabled	<p>To reenable system:</p> <ul style="list-style-type: none"> <li>• Cycle engine start switch key OR</li> <li>• Press and hold top position of Regen Switch for at least 2 seconds</li> </ul>

## OTHER ACTIONS

### To FORCE a regeneration:

1. Stop machine
2. Put transmission in neutral\*



3. Check soot level monitor to make sure DPF is at least 15% full

\*If applicable..

4. Apply parking brake\*



Parking Brake

5. Press and hold top position of the Regen Switch for a minimum of 2 seconds



Regen Switch

### To DISABLE a regeneration:

Press and hold bottom position of the Regen Switch for a minimum of 2 seconds



Regen Switch

## QUESTIONS? Contact your local Cat Dealer.

© 2012 Caterpillar. All Rights Reserved. Printed in USA. CAT, CATERPILLAR, their respective logos, "Caterpillar Yellow" and the "Power Edge" trade dress as well as corporate and product identity used herein, are trademarks of Caterpillar and may not be used without permission..

AEX00681 (3/2012)

